

1		2		3		4		5		6	
支吊架编号											
名称		单拉杆刚性吊架		单拉杆刚性吊架		单拉杆刚性吊架		单拉杆刚性吊架		单拉杆刚性吊架	
管道外径 ϕ (mm)		$\phi 720$		$\phi 720$		$\phi 720$		$\phi 500$		$\phi 500$	
设计温度($^{\circ}\text{C}$)		50		50		50		50		50	
工作 $F_x; F_y; F_z$ (N)		0	0	0	0	0	0	0	0	0	0
荷重 $M_x; M_y; M_z$ (N*m)		0	0	0	0	0	0	0	0	0	0
结构 $F_x; F_y; F_z$ (N)		0	0	0	0	0	0	0	0	0	0
荷重 $M_x; M_y; M_z$ (N*m)		0	0	0	0	0	0	0	0	0	0
冷态位移 $D_x; D_y; D_z$ (mm)		0	0	0	0	0	0	0	0	0	0
热态位移 $D_x; D_y; D_z$ (mm)		0	0	0	0	0	0	0	0	0	0
安装载荷(N)/弹簧压缩值(mm)		0	—	0	—	0	—	0	—	0	—
根部标高(m)		11.300		11.260		11.372		12.550		12.620	
根部标高(m)		14.150/—		14.560/—		14.150/—		14.900/—		14.900/—	
偏差值 $x; y; z$ (mm)		0	0	0	0	0	0	0	0	0	0
制作套数		所开列1号机组用量		所开列1号机组用量		所开列1号机组用量		所开列1号机组用量		所开列1号机组用量	
B	支	3091101	3090901	3090901	3090901	3090701	3090701	3090701	3090701	3090701	3090701
	吊	3091101	3090901	3090901	3090901	3090701	3090701	3090701	3090701	3090701	3090701
	架	3121101	3120901	3120901	3120901	3120701	3120701	3120701	3120701	3120701	3120701
	体	4071101	4070901	4070901	4070901	4070701	4070701	4070701	4070701	4070701	4070701
	整	3061199(1800)	3060999(2480)	3060999(1950)	3060799(1710)	3060799(1640)	3060799(1640)	3060799(1640)	3060799(1640)	3060799(1640)	3060799(1640)
	架	3091101	3090901	3090901	3090901	3090701	3090701	3090701	3090701	3090701	3090701
	体	3031101	3030901	3030901	3030901	3030701	3030701	3030701	3030701	3030701	3030701
	整	3051199(400)	3050999(350)	3050999(350)	3050799(270)	3050799(270)	3050799(270)	3050799(270)	3050799(270)	3050799(270)	3050799(270)
	架	3091101	3090901	3090901	3090901	3090701	3090701	3090701	3090701	3090701	3090701
	体	3011101	3010901	3010901	3010901	3010701	3010701	3010701	3010701	3010701	3010701
结构	102120720	101110720	101110720	101110500	101110500	101110500	101110500	101110500	101110500	101110500	
C	备	安装示意图见Fdemo-0001-01 图 1		安装示意图见Fdemo-0001-01 图 2		安装示意图见Fdemo-0001-01 图 2		安装示意图见Fdemo-0001-01 图 2		安装示意图见Fdemo-0001-01 图 2	
	注										
D	说明:	1. 布置图见 F05831S-J1407-03 1/3-3/3; 2. 支吊架示意图见 F05831S-J1407-07 1/2-2/2; 3. K 不小于被焊件最小厚度, 焊接要求详见《发电厂汽水管道支吊架示意图设计手册(D-ZD2010)》; 4. 1 号机组按图制作一套; 5. 本图列表中的工作荷载和结构荷载不包括支吊架管夹、恒吊、弹吊及连接附件等自重; 6. 本图的坐标以 A 排和 1 轴的交叉点为原点, 从 1 轴到 2 轴的方向为 X 轴负向, 从 A 排到 B 排方向为 Y 轴正向, 垂直于主厂房土 0.000m 向上为 Z 轴正向。									